

Technical Bulletin

By default setting, the AS203 doesn't notice the user in any form when it's a good data read for a barcode, since it doesn't have a buzzer, nor a vibrator; however we can enable the barcode scanner's LED light to flash twice as a notification of a successful read.

Good Read Flash :

Applied to F/W: SM3-d-1.23.KBM





Steps: Scan <.A103\$> or <.A104\$>